WARNING

1. Do not use this sling if a patient needs neck or head support.
2. Please read and understand the lifter operating instructions before use.
3. Do not use sling if a patient suffers from back injury.

General Purpose Sling Lifting Procedures

KH406NE1 - 20kg-40kg
KH406NE2 - 40kg-150kg

STEP 1: Slide the sling down the back of the chair until point (B) aligns with the base of the spine.

STEP 2: Slide the leg supports (C) under the leg and cross-over for extra support or leave separated to divide the legs for toileting.
STEP 3: Bring the lifter into position, ensure hoist legs are gated and the hoist yoke is approximately over the centre of the patient.
DO NOT engage the brakes on the castors.

CHAIR TO CHAIR LIFT
STEP 4: Raise the patient in a seated position. To do this, fit strap (A) and strap (C) to the yoke, using the most comfortable and safe colour straps for the patient. Check to see if the sling is comfortable and slowly raise the hoist. CAUTION: Hoist may move towards the patient when you raise the boom.
STEP 5: Position the patient over the chair and lower slowly. Pull on the back straps if necessary to locate the patients back into the chair.

CHAIR TO BED LIFT
Follow STEPS 1, 2 and 3 for fitting instructions from chair.
STEP 4: Raise the patient in a laying back position. To do this, fit the YELLOW or GREEN strap (A) and the RED or YELLOW strap (C) to the yoke. Check to see if the sling is comfortable and slowly raise the hoist.
CAUTION: Hoist may move towards the patient when you raise the boom.
STEP 5: Position the patient over the bed and lower slowly.

FITTING INSTRUCTIONS FROM FLOOR OR BED
STEP 1: Roll the patient onto their side. Concertina the sling under the patients back. Align (B) with the base of the patients spine.
STEP 2: Roll the patient onto the sling and centralize. Bring the lifter into position, ensure hoist legs are fully gated and the hoist yoke is approximately over the centre of the patient.
FROM FLOOR OR BED.

FLOOR TO CHAIR LIFT
Follow STEPS 1, 2 and 3 for FITTING INSTRUCTIONS FROM FLOOR OR BED.
STEP 3: Fit strap (A) and strap (C) to the yoke, using the colour most comfortable and safe. Check to see if the sling is comfortable and slowly raise the hoist.
CAUTION: Hoist may move towards the patient when you raise the boom.
STEP 4: Position the patient over the chair and lower slowly. Pull on the back straps as necessary to locate the patients back into the chair.

FLOOR TO BED LIFT
Follow STEPS 1, 2 and 3 for fitting instruction from floor to bed.
STEP 4: Fit strap (A) and strap (C) to the yoke, using the colour most comfortable and safe. Check to see if the sling is comfortable and slowly raise the hoist.
CAUTION : Hoist may move towards the patient when you raise the boom.
STEP 5: Position the patient over the bed and lower slowly.

CARE INSTRUCTIONS

1. Sling Care

Protect from direct sunlight.
Do not puncture with any sharp objects.
Repair any tear immediately.
Do not lift a patient if there are any sling defects.
Washing and drying temperature must not exceed 60 degrees.

2. Spot Cleaning

The sling is machine washable.
Treat spills and stains as soon as possible.
Gently scrape away any soils or mop away liquid from surface of fabric with damp cloth.

Kerry Equipment™
A Hills Company

4 Halley Rd
Balcatta WA 6021
Tel: 08 9240 2944
Fax: 08 9240 1469
Email: info@kerryequipment.com.au
Website: www.kerryequipment.com.au

PATIENT RECORDS FOR MOUNTING POINTS
USING KH406NE1, KH406NE2, KH406NE3

Name of Patient	Sling size	Laying	Seated	Strap colour (A)	Strap colour (C)

USERS GUIDE
KH406NE
GENERAL PURPOSE SLING

FEATURES
Mesh/netting option KH406NE
Quick and easy to fit
Ideal for bathing
Excellent back support and comfort
Colour coded attachment straps
Positioning straps
Machine washable

Kerry Equipment™
A Hills Company